



TENT SET UP INSTRUCTIONS



- A 7' Side Pole
- B 14' Center Pole (2 Piece)
- C 36' Tent Stake
- D Tent Canopy
- E Ropes (Attached to Top)

- ➔ Lay out the tent in the desired location making sure the tent is **completely flat**
- ➔ Drive stakes into the ground approximately 5' out from each gromet on the tent. There are 2 stakes in each corner and 1 stake for each side rope



- ➔ Tie each rope to the stakes you have driven into the ground. Leave 3' - 4' of slack so you are able to easily stand up the sidepoles in the following step. It is best to use a slip knot to the ropes are more easily tightened.
- ➔ Put the 7' sidepoles in place by pushing them into place from under the canvas. Tighten the corner ropes enough to hold the poles into position.
- ➔ Place the 14' center pole in place and make sure the pole is in the **middle** of the tent.
- ➔ Tighten all the ropes around the tent so that the corners are creased and do not sag. It is best to tighten the corners alternately across the diagonal dimensions of the tent. This maintains uniform tension at the top.

5 CONVENIENT LOCATIONS!

FARIBAULT

504 WILSON AVE
FARIBAULT, MN
(507)334-8440

OWATONNA

333 W NORTH ST
OWATONNA, MN
(507)455-0000

NORTHFIELD

1680 S HWY 3
NORTHFIELD, MN
(507)645-4958

WASECA

1600 W ELM AVE
WASECA, MN
(507)835-5055

AUSTIN

2307 NW 4TH ST
AUSTIN, MN
(507)433-9172